In the information that follows, you will find that the part number is followed by the Phrase "The Part Number: "
The part number is about 14 characters long and is followed by a description beginning with " a for ".
Headings between types of part numbers are lines that start with a space character instead of a letter or number.

EcoStructure Building Operation - Enterprise Central Software for Windows
The Part Number: SWKSWECXX00002 is for Enterprise Central Software for Windows – 2 Servers
The Part Number: SWKSWECXX00005 is for Enterprise Central Software for Windows – 5 Servers
The Part Number: SWKSWECXX00010 is for Enterprise Central Software for Windows – 10 Servers
The Part Number: SWKSWESEC00003 is for Add 3 Enterprise Servers To The Enterprise Central Server - Windows
The Part Number: SWKSWESEC00005 is for Add 5 Enterprise Servers To The Enterprise Central Server - Windows
EcoStructure Building Operation - Enterprise Central Software for Windows - Version Upgrades for Existing Accounts currently at version 2.x to version 3.x
The Part Number: SWKSWECUP23005 is for Enterprise Central for Windows Upgrade from version 2.x to version 3.x – 5 Servers
The Part Number: SWKSWECUP23010 is for Enterprise Central for Windows Upgrade from version 2.x to version 3.x – 10 Servers
EcoStructure Building Operation - Enterprise Central Software for Windows - Version Upgrades for Existing Accounts currently at version 3.x to version 6.x (EBO2024)
The Part Number: SWKSWECUP30005 is for Enterprise Central for Windows Upgrade from version 3.x to version 6.x (EBO2024) – 5 Servers
The Part Number: SWKSWECUP30010 is for Enterprise Central for Windows Upgrade from version 3.x to version 6.x (EBO2024) – 10 Servers
EcoStructure Building Operation - Enterprise Central Software for Windows - Version Upgrades for Existing Accounts currently at version 4.x to version 6.x (EBO2024)
The Part Number: SWKSWECUP40002 is for Enterprise Central for Windows Upgrade from version 3.x to current version for up to 10 AS-P or AS-B Controllers*
The Part Number: SWKSWECUP40005 is for Enterprise Central for Windows Upgrade from version 3.x to current version for up to 50 AS-P or AS-B Controllers*
The Part Number: SWKSWECUP40010 is for Enterprise Central for Windows Upgrade from version 3.x to current version for up to 100 AS-P or AS-B Controllers*
EcoStructure Building Operation - Enterprise Central Software for Linux
The Part Number: SWKSWECLX00002 is for Enterprise Central Software for Linux – 2 Servers
The Part Number: SWKSWECLX00005 is for Enterprise Central Software for Linux – 5 Servers
The Part Number: SWKSWECLX00010 is for Enterprise Central Software for Linux – 10 Servers
The Part Number: SWKSWESEC L0003 is for Add 3 Enterprise Servers To The Enterprise Central Server - Linux
The Part Number: SWKSWESEC L0005 is for Add 5 Enterprise Servers To The Enterprise Central Server - Linux
EcoStructure Building Operation - Enterprise Server Software for Windows
The Part Number: SWKSWESEXX00010 is for Enterprise Server for Windows for up to 10 AS-P or AS-B Controllers (includes 3 workstation standard or webstation)
The Part Number: SWKSWESEXX00050 is for Enterprise Server for Windows for up to 50 AS-P or AS-B Controllers (includes 3 workstation standard or webstation)
The Part Number: SWKSWESEXX00100 is for Enterprise Server for Windows for up to 100 AS-P or AS-B Controllers (includes 3 workstation standard or webstation)
The Part Number: SWKSWESEXX00250 is for Enterprise Server for Windows for up to 250 AS-P or AS-B Controllers (includes 3 workstation standard or webstation)
The Part Number: SWKSWASESX0001 is for Enterprise Server for Windows Hosting Pack for 1 AS-P or AS-B (Upgrade for AS connection)
The Part Number: SWKSWASESX0010 is for Enterprise Server for Windows Hosting Pack for 10 AS-P or AS-B (Upgrade for AS connection)
The Part Number: SWKSWASESX0050 is for Enterprise Server for Windows Hosting Pack for 50 AS-P or AS-B (Upgrade for AS connection)
EcoStructure Building Operation - Device Packs to be hosted directly by Enterprise Server Software for Windows
The Part Number: SWKSWNDES00005 is for Device Pack for Windows - 5 Devices
The Part Number: SWKSWNDES00010 is for Device Pack for Windows – 10 Devices
The Part Number: SWKSWNDES00025 is for Device Pack for Windows - 25 Devices
The Part Number: SWKSWNDES00050 is for Device Pack for Windows – 50 Devices
The Part Number: SWKSWNDES00100 is for Device Pack for Windows – 100 Devices
The Part Number: SWKSWNDES00300 is for Device Pack for Windows – 300 Devices
The Part Number: SWKSWNDES00600 is for Device Pack for Windows – 600 Devices
EcoStructure Building Operation - Enterprise Server Software for Windows - Version Upgrades for Existing Accounts currently at version 4.x (EBO 2022) or version 5.x (EBO 2023) to version 6.x (EBO 2024)
The Part Number: SWKSWESUP40010 is for Enterprise Server for Windows Upgrade from version 4.x (EBO 2022) or 5.x (EBO 2023) to current version for up to 10 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP40050 is for Enterprise Server for Windows Upgrade from version 4.x (EBO 2022) or 5.x (EBO 2023) to current version for up to 50 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP40100 is for Enterprise Server for Windows Upgrade from version 4.x (EBO 2022) or 5.x (EBO 2023) to current version for up to 100 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP40250 is for Enterprise Server for Windows Upgrade from version 4.x (EBO 2022) or 5.x (EBO 2023) to current version for up to 250 AS-P or AS-B Controllers*
EcoStructure Building Operation - Enterprise Server Software for Windows - Version Upgrades for Existing Accounts currently at version 3.x to version 6.x (EBO2024)
The Part Number: SWKSWESUP30010 is for Enterprise Server for Windows Upgrade from version 3.x to current version for up to 10 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP30050 is for Enterprise Server for Windows Upgrade from version 3.x to current version for up to 50 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP30100 is for Enterprise Server for Windows Upgrade from version 3.x to current version for up to 100 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP30250 is for Enterprise Server for Windows Upgrade from version 3.x to current version for up to 250 AS-P or AS-B Controllers*
EcoStructure Building Operation - Enterprise Server Software for Windows - Version Upgrades for Existing Accounts currently at version 2.x to version 3.x
The Part Number: SWKSWESUP23010 is for Enterprise Server for Windows Upgrade from version 2.x to version 3.x for up to 10 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP23050 is for Enterprise Server for Windows Upgrade from version 2.x to version 3.x for up to 50 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP23100 is for Enterprise Server for Windows Upgrade from version 2.x to version 3.x for up to 100 AS-P or AS-B Controllers*
The Part Number: SWKSWESUP23250 is for Enterprise Server for Windows Upgrade from version 2.x to version 3.x for up to 250 AS-P or AS-B Controllers*
EcoStructure Building Operation - Enterprise Server Software for Windows - Version Upgrades for Existing Accounts currently at version 1.x to 3.x
The Part Number: SWKSWESUP13010 is for Enterprise Server for Windows Upgrade from version 1.x to version 3.x for up to 10 AS-P or AS-B Controllers
The Part Number: SWKSWESUP13050 is for Enterprise Server for Windows Upgrade from version 1.x to version 3.x for up to 50 AS-P or AS-B Controllers
The Part Number: SWKSWESUP13100 is for Enterprise Server for Windows Upgrade from version 1.x to version 3.x for up to 100 AS-P or AS-B Controllers
The Part Number: SWKSWESUP13250 is for Enterprise Server for Windows Upgrade from version 1.x to version 3.x for up to 250 AS-P or AS-B Controllers
The Part Number: SWKSWASUP00001 is for AS Upgrade
The Part Number: SWKSWASUP00099 is for AS Upgrade - Unlimited
EcoStructure Building Operation - Enterprise Server Software for Linux
The Part Number: SWKSWESLX00010 is for Enterprise Server for Linux for up to 10 AS-P or AS-B Controllers (includes 3 workstation standard or webstation)
The Part Number: SWKSWESLX00050 is for Enterprise Server for Linux for up to 50 AS-P or AS-B Controllers (includes 3 workstation standard or webstation)
The Part Number: SWKSWESLX00100 is for Enterprise Server for Linux for up to 100 AS-P or AS-B Controllers (includes 3 workstation standard or webstation)
The Part Number: SWKSWESLX00250 is for Enterprise Server for Linux for up to 250 AS-P or AS-B Controllers (includes 3 workstation standard or webstation)
The Part Number: SWKSWASESL0001 is for Enterprise Server for Linux Hosting Pack for 1 AS-P or AS-B (Upgrade for AS connection)
The Part Number: SWKSWASESL0010 is for Enterprise Server for Linux Hosting Pack for 10 AS-P or AS-B (Upgrade for AS connection)
The Part Number: SWKSWASESL0050 is for Enterprise Server for Linux Hosting Pack for 50 AS-P or AS-B (Upgrade for AS connection)
EcoStructure Building Operation – Device Packs to be hosted by Enterprise Server Software for Linux directly
The Part Number: SWKSWNDES L0005 is for Device Pack for Linux - 5 Devices
The Part Number: SWKSWNDES L0010 is for Device Pack for Linux – 10 Devices
The Part Number: SWKSWNDES L0025 is for Device Pack for Linux - 25 Devices
The Part Number: SWKSWNDES L0050 is for Device Pack for Linux – 50 Devices
The Part Number: SWKSWNDES L0100 is for Device Pack for Linux - 100 Devices
The Part Number: SWKSWNDES L0300 is for Device Pack for Linux – 300 Devices
The Part Number: SWKSWNDES L0600 is for Device Pack for Linux - 600 Devices
EcoStructure Building Operation – Edge Server Software
The Part Number: SWKSWEBUX00005A is for Edge Server - Standalone Software Supports hosting up to 10 Connected Products - no support to be hosted under an Enterprise Server
The Part Number: SWKSWEBUX00005D is for Edge Server - Standard Software Supports hosting up to 25 Connected Products
The Part Number: SWKSWEBUX00005N is for Edge Server - Enhanced Software Supports hosting up to 100 Connected Products
The Part Number: SWKSWEBUX00005F(L) is for Edge Server - Full Software Supports hosting up to 250 Connected Products
The Part Number: SWKSWEUPX05A5D is for Edge Server Bundle upgrade - Standalone to Standard Upgrade from hosting 10 to 25 Connected Products
The Part Number: SWKSWEUPX05A5N is for Edge Server Bundle upgrade - Standalone to Enhanced Upgrade from hosting 10 to 100 Connected Products
The Part Number: SWKSWEUPX05A5FU is for Edge Server Bundle upgrade - Standalone to Full Upgrade from hosting 10 to 250 Connected Products
The Part Number: SWKSWEUPX05D5N is for Edge Server Bundle upgrade - Standard to Enhanced Upgrade from hosting 25 to 100 Connected Products
The Part Number: SWKSWEUPX05D5FU is for Edge Server Bundle upgrade - Standard to Full Upgrade from hosting 25 to 250 Connected Products
The Part Number: SWKSWEUPX05ENFU is for Edge Server Bundle upgrade - Enhanced to Full Upgrade from hosting 100 to 250 Connected Products
EcoStructure Building Operation Edge Server - Version Upgrades for Existing Accounts from version 5.x to 6.x (EBO 2024)
The Part Number: SWKSWEDGUP5E6N is for Edge Server Update from version 5.x to 6.x (EBO 2024) - Enhanced
The Part Number: SWKSWEDGUP5E6FU is for Edge Server Update from version 5.x to 6.x (EBO 2024) - Full
The Part Number: SWKSWEDGUP5E6A is for Edge Server Update from version 5.x to 6.x (EBO 2024) – Standalone
The Part Number: SWKSWEDGUP5E6D is for Edge Server Update from version 5.x to 6.x (EBO 2024) - Standard
Enterprise Central and Enterprise Server Add-on Options for Windows
The Part Number: SWKSWGWEX00001 is for Web Services (Generic Consume) option (no maintenance subscription included)
The Part Number: SWKSWEWEX00001 is for EcoStructure Web Services (run-time) option – Consume only (no maintenance subscription included)
The Part Number: SWKSWEWEX00002 is for EcoStructure Web Services (run-time) option – Serve & Consume (no maintenance subscription included)
The Part Number: SWKSWEWSX00002 is for EcoStructure Web Services (run-time) option – Serve & Consume, plus Historical trend log data (no maintenance subscription included)
The Part Number: SWKSWSNMP00001 is for Alarm notifications via SNMP option (no maintenance subscription included)
The Part Number: SWKSWDASHX0001 is for Personal Dashboards
The Part Number: SWKSWECDBT5001 is for Timescale Database Option - Enterprise Central
The Part Number: SWKSWESDBT5001 is for Timescale Database Option - Enterprise Server
The Part Number: SWKSWCMPLPK001 is for EcoStructure Building Operation License for Compliance Pack, Change Control, Timescale Database, Digital Signing
The Part Number: SWKSWECPXFS001 is for EcoStructure Building Operation License, Allows Digital Signed Certificates For Reports From The Enterprise Central
The Part Number: SWKSWESPXFS001 is for EcoStructure Building Operation License, Allows Digital Signed Certificates For Reports From The Enterprise Server
The Part Number: SWKSWMQTTSRW01 is for EcoStructure Building Operation License, Allows Enterprise Server To Publish & Subscribe Data To An MQTT Broker
The Part Number: SWKSWSTDBAC002 is for EcoStructure Building Operation License, Semantic Tagging DB - Plus CPU Cores: 2
The Part Number: SWKSWSTDBAC006 is for EcoStructure Building Operation License, Semantic Tagging DB - Plus CPU Cores: 6
The Part Number: SWKSWSTDBELIAC2 is for EcoStructure Building Operation License, Semantic Tagging DB - External Use Plus Cores: 2
The Part Number: SWKSWSTDBELIAC6 is for EcoStructure Building Operation License, Semantic Tagging DB - External Use Plus Cores: 6
The Part Number: SWKSWECSAML001 is for EcoStructure Building Operation License, SAML Authentication: Enterprise Central
The Part Number: SWKSWESAML001 is for EcoStructure Building Operation License, SAML Authentication: Enterprise Server
The Part Number: SWKSWESSDZR001 is for EcoStructure Building Operation License, Allows Zoning For The Enterprise Server and connected SpaceLogic Edge Servers
The Part Number: SWKSWECDBMS001 is for MS SQL database option, EcoStructure Building Operation, EBO 2023, for enterprise central
The Part Number: SWKSWESDBMS001 is for MS SQL database option, EcoStructure Building Operation, EBO 2023, for enterprise server
The Part Number: SWKSWECDBPB001 is for Building Operation - PI System - EC
The Part Number: SWKSWESDBPB001 is for Building Operation - PI System - ES
The Part Number: SWKSWECSUSPN001 is for EBO Sustainability Pack - EC
The Part Number: SWKSWESSUSPN001 is for EBO Sustainability Pack - ES
The Part Number: SWKSWESOPCL001 is for EBO OPC UA Client - ES
EcoStructure Building Operation Client Software - User Interface for Windows
The Part Number: SWKSWCLIENT001 is for WorkStation Software Standard or Webstation (1 concurrent user license)
The Part Number: SWKSWCLIENT005 is for WorkStation Software Standard or Webstation (5 concurrent user license)
The Part Number: SWKSWCLIENT010 is for WorkStation Software Standard or Webstation (10 concurrent user license)
The Part Number: SWKSWCLIENT025 is for WorkStation Software Standard or Webstation (25 concurrent user license)
The Part Number: SWKSWCLIENTU99 is for WorkStation Software Standard or Webstation (unlimited user license)
EcoStructure Building Operation Tools
The Part Number: SWKSWWORK0002 is for WorkStation Software Professional, includes Programming & Graphics Editors (1 concurrent user license)
The Part Number: SWKSWEDT00001 is for Programming & Graphics Editors (1 concurrent user license)
The Part Number: SWKSWEDT00002 is for EBO Graphics Editor only - 1 User
Enterprise Central and Enterprise Server Add-on Options for Linux
The Part Number: SWKSWGWEL0001 is for Web Services (Generic Consume) option (no maintenance subscription included)
The Part Number: SWKSWEWEL0001 is for EcoStructure Web Services (run-time) option – Consume only (no maintenance subscription included)
The Part Number: SWKSWEWEL0002 is for EcoStructure Web Services (run-time) option – Serve & Consume (no maintenance subscription included)
The Part Number: SWKSWEWSL0002 is for EcoStructure Web Services (run-time) option – Serve & Consume, plus Historical trend log data (no maintenance subscription included)
The Part Number: SWKSWSNMPL0001 is for Alarm notifications via SNMP option (no maintenance subscription included)
The Part Number: SWKSWDASHL0001 is for Personal Dashboards
The Part Number: SWKSWECDBTSL01 is for Timescale Database Option - Enterprise Central
The Part Number: SWKSWESDBTSL01 is for Timescale Database Option - Enterprise Server
The Part Number: SWKSWCMPLPKL01 is for EcoStructure Building Operation License for Compliance Pack, Change Control, Timescale Database, Digital Signing
The Part Number: SWKSWECPXFSSL1 is for EcoStructure Building Operation License, Allows Digital Signed Certificates For Reports From The Enterprise Server
The Part Number: SWKSWESPXFSSL1 is for EcoStructure Building Operation License, Allows Digital Signed Certificates For Reports From The Enterprise Server
The Part Number: SWKSWMQTTSRWL1 is for EcoStructure Building Operation License, Allows Enterprise Server To Publish & Subscribe Data To An MQTT Broker
The Part Number: SWKSWECSAML1L01 is for EcoStructure Building Operation License, SAML Authentication: Enterprise Central
The Part Number: SWKSWESSAML1L01 is for EcoStructure Building Operation License, SAML Authentication: Enterprise Server
The Part Number: SWKSWESSDZRL01 is for EcoStructure Building Operation License, Allows Zoning For The Enterprise Server and connected SpaceLogic Edge Servers
The Part Number: SWKSWECDBMSL01 is for MS SQL database option, EcoStructure Building Operation, EBO 2023, for enterprise central
The Part Number: SWKSWESDBMSL01 is for MS SQL database option, EcoStructure Building Operation, EBO 2023, for enterprise server
The Part Number: SWKSWECDBPL01 is for Building Operation - PI System - EC
The Part Number: SWKSWESDBPL01 is for Building Operation - PI System - ES
The Part Number: SWKSWECSUSPNL1 is for EBO Sustainability Pack - EC
The Part Number: SWKSWESSUSPNL1 is for EBO Sustainability Pack - ES
The Part Number: SWKSWESOPCLL01 is for EBO OPC UA Client - ES
EcoStructure Building Operation Client Software - User Interface for Linux
The Part Number: SWKSWCLIENTL001 is for WorkStation Software Standard or Webstation (1 concurrent user license)
The Part Number: SWKSWCLIENTL005 is for WorkStation Software Standard or Webstation (5 concurrent user license)
The Part Number: SWKSWCLIENTL010 is for WorkStation Software Standard or Webstation (10 concurrent user license)
The Part Number: SWKSWCLIENTL025 is for WorkStation Software Standard or Webstation (25 concurrent user license)
The Part Number: SWKSWCLIENTL99 is for WorkStation Software Standard or Webstation (unlimited user license)
SpaceLogic Add-on Options
The Part Number: SWKSWASDBXS001 is for Timescale Database Option - SpaceLogic
The Part Number: SWKSWGWSX00001 is for EBO WS Gen Consume - SpaceLogic
The Part Number: SWKSWEWSX00001 is for EBO WS EWS Consume - SpaceLogic
The Part Number: SWKSWEWSX00002 is for EBO WS EWS C+Serve - SpaceLogic
The Part Number: SWKSWEWSX00003 is for EBO WS EWS C+S+Hist - SpaceLogic
The Part Number: SWKSWSNMPX0001 is for EBO SNMP Alarming - SpaceLogic
The Part Number: SWKSWDSPX00001 is for EBO SmartDriver - SpaceLogic
The Part Number: SWKSWASDBPX001 is for Building Operation - PI System - AS
The Part Number: SWKSWASUSPN1 is for EBO Sustainability Pack - 1 AS or Edge Server
The Part Number: SWKSWASKOPCL01 is for EBO OPC UA Client - AS
The Part Number: SWKSWMQTTSRW01 is for EcoStructure Building Operation License, Allows SpaceLogic Server To Publish & Subscribe Data To An MQTT Broker
The Part Number: SWKSWASDBMS001 is for MS SQL database option, EcoStructure Building Operation, EBO 2023, for 1 SpaceLogic server
The Part Number: SWKSWASAML001 is for EcoStructure Building Operation License, SAML Authentication: SpaceLogic
The Part Number: SWKSWSNMPX0001 is for Alarm notifications via SNMP option (no maintenance subscription included)
The Part Number: SWKSWASSDZR001 is for EcoStructure Building Operation License, Allows Zoning For The Automation Server
The Part Number: SWKSWDASHX0001 is for Personal Dashboards - SpaceLogic
The Part Number: SWKSWASDRVN001 is for Building Operation - SmartDriver JN2 - AS
Scalable Automation Servers (AS-P) - Secure Boot Hardware & Software - can only be used on site at EBO 2023 and newer
The Part Number: SWKASPS8A10001 is for SpaceLogic Controller AS-P Secure Boot Hardware (Hardware Only - Requires ASP Software Bundle)
The Part Number: SWKASPS8X10002 is for SpaceLogic Controller AS-P-NaLON Secure Boot Hardware (Hardware Only - Requires ASP Software Bundle)
The Part Number: SWKASPS8X8 10A01 is for SpaceLogic AS-P-S8A Automation Server, Power Supply Module, AS-P Terminal Base, Power Supply Terminal Base, Buy American Act
The Part Number: SWKASPS8X11A01 is for SpaceLogic Automation Server, LonWorks, 2 RS-485 Ports, 2 10/100 Ethernet Ports, Secure Boot, Buy American Act
The Part Number: SWKSWKBUX00005A is for ASP Software Bundle - Standalone Software Supports hosting up to 10 Connected Products - no support to be hosted under an Enterprise Server
The Part Number: SWKSWKBUX00005D is for ASP Software Bundle - Standard Software Supports hosting up to 25 Connected Products
The Part Number: SWKSWKBUX00005N is for ASP Software Bundle - Enhanced Software Supports hosting up to 100 Connected Products
The Part Number: SWKSWKBUX00005F(L) is for ASP Software Bundle - Full Software Supports hosting up to 250 Connected Products
The Part Number: SWKSWX00SWBRTU is for SpaceLogic AS-P Server (SW) Modbus TCP or RTU Enablement
Scalable Automation Servers (AS-P) - Secure Boot Software - Connected Product Hosting Capacity Upgrades
The Part Number: SWKSWKUPX05A5D is for ASP Software Bundle upgrade - Standalone to Standard Upgrade from hosting 10 to 25 Connected Products
The Part Number: SWKSWKUPX05A5N is for ASP Software Bundle upgrade - Standalone to Enhanced Upgrade from hosting 10 to 100 Connected Products
The Part Number: SWKSWKUPX05A5FU is for ASP Software Bundle upgrade - Standalone to Full Upgrade from hosting 10 to 250 Connected Products
The Part Number: SWKSWKUPX05D5N is for ASP Software Bundle upgrade - Standard to Enhanced Upgrade from hosting 25 to 100 Connected Products
The Part Number: SWKSWKUPX05D5FU is for ASP Software Bundle upgrade - Standard to Full Upgrade from hosting 25 to 250 Connected Products
The Part Number: SWKSWKUPX0ENFU is for ASP Software Bundle upgrade - Enhanced to Full Upgrade from hosting 100 to 250 Connected Products
Automation Servers (P) Classic (ASI-P Controllers) - Non-Secure Boot Hardware & Software upgrades from version 3.x and version 4.x to current release of EBO
The Part Number: SWKASPXX01X001 is for SpaceLogic Controller AS-P Classic (HW)
The Part Number: SWKASPXX01X002 is for SpaceLogic Controller AS-P NL Classic (HW)
The Part Number: SWKASPXX01X001 is for SpaceLogic Controller AS-P Smoke Classic (HW)
The Part Number: SWKSWASPUP3E5A is for ASP Upgrade Non-Secure Boot SpaceLogic Server - Standalone - supports hosting up to 10 Connected Products / does not support being hosted under an ES - Required for upgrading from version 3.x to current release of EBO
The Part Number: SWKSWASPUP3E5D is for ASP Upgrade Non-Secure Boot SpaceLogic Server - Standard - supports hosting up to 25 Connected Products - Required for upgrading from version 3.x to current release of EBO
The Part Number: SWKSWASPUP3E5N is for ASP Upgrade Non-Secure Boot SpaceLogic Server - Enhanced - supports hosting up to 100 Connected Products - Required for upgrading from version 3.x to current release of EBO
The Part Number: SWKSWASPUP3EFU is for ASP Upgrade Non-Secure Boot SpaceLogic Server - Full - supports hosting up to 250 Connected Products - Required for upgrading from version 3.x to current release of EBO
The Part Number: SWKSWASPUP3EBF is for ASP Bulk Pack - Upgrade a maximum of 125 Non-Secure Boot SpaceLogic Servers from version 3.x to current release of EBO - each ASP will be licensed with Full capacity to support hosting up to 250 Connected Products
The Part Number: SWKSWASPUP4E5A is for ASP Upgrade Non-Secure Boot SpaceLogic Server - Standalone - supports hosting up to 10 Connected Products / does not support being hosted under an ES - Required for upgrading from version 4.x to current release of EBO
The Part Number: SWKSWASPUP4E5D is for ASP Upgrade Non-Secure Boot SpaceLogic Server - Standard - supports hosting up to 25 Connected Products - Required for upgrading from version 4.x to current release of EBO
The Part Number: SWKSWASPUP4E5N is for ASP Upgrade Non-Secure Boot SpaceLogic Server - Enhanced - supports hosting up to 100 Connected Products - Required for upgrading from version 4.x to current release of EBO
The Part Number: SWKSWASPUP4EFU is for ASP Upgrade Non-Secure Boot SpaceLogic Server - Full - supports hosting up to 250 Connected Products - Required for upgrading from version 4.x to current release of EBO
The Part Number: Scalable Automation Servers Bundled (AS-B) - Secure Boot Hardware & Software - can only be used on site at EBO 2022 and newer is for Scalable Automation Servers Bundled (AS-B) - Secure Boot Hardware & Software - can only be used on site at EBO 2022 and newer
The Part Number: SWKASBB24HP10001 is for AS-B controller with 24 I/O points (12 Universal Type A, 4 Universal Type B, 4 Digital Inputs and 4 Digital Outputs) with manual overrides Hardware Only - Requires ASP Software Bundle selected based on quantity of Connected Products to be
The Part Number: SWKASBB36HP10001 is for AS-B controller with 36 I/O points (20 Universal Type A, 8 Universal Type B, 4 Digital Outputs, Relay and 4 Digital Outputs Triac) with manual overrides Hardware Only - Requires ASP Software Bundle selected based on quantity of Connected
The Part Number: SWKSWKBBU01002 is for ASB Software Bundle - Standard Supports hosting up to 10 Connected Devices
The Part Number: SWKSWKBBU005F(L) is for ASB Software Bundle - Full Supports hosting up to 50 Connected Devices
Scalable Automation Servers Bundled (AS-B) - Secure Boot Software - Connected Product Hosting Capacity Upgrades
The Part Number: SWKSWKBBUPX5FU is for ASB Bundle capacity upgrade - Standard to Full Upgrade from hosting up to 10 to 50 Connected Products
Automation Servers Bundled Classic (AS-B) - Non-Secure Boot Hardware & Software upgrades from version 3.x to current release of EBO
The Part Number: SWKASB24X10001 is for AS-B controller with 24 I/O points (12 Universal Type A, 4 Universal Type B, 4 Digital Inputs and 4 Digital Outputs) - hosting up to 50 controllers on BACnet MS/TP bus
The Part Number: SWKASB36X10001 is for AS-B controller with 36 I/O points (20 Universal Type A, 8 Universal Type B, 4 Digital Outputs, Relay and 4 Digital Outputs Triac) - hosting up to 50 controllers on BACnet MS/TP bus
The Part Number: SWKASB24H10001 is for AS-B controller with 24 I/O points (12 Universal Type A, 4 Universal Type B, 4 Digital Inputs and 4 Digital Outputs) with manual overrides - hosting up to 50 controllers on BACnet MS/TP bus
The Part Number: SWKASB36H10001 is for AS-B controller with 36 I/O points (20 Universal Type A, 8 Universal Type B, 4 Digital Outputs, Relay and 4 Digital Outputs Triac) with manual overrides - hosting up to 50 controllers on BACnet MS/TP bus
The Part Number: SWKSWASBUP3E5D is for ASB Upgrade Non-Secure Boot SpaceLogic Server - Standard - supports hosting up to 10 Connected Products - Required for upgrading from version 3.x to current release of EBO
The Part Number: SWKSWASBUP3EFU is for ASB Upgrade Non-Secure Boot SpaceLogic Server - Full - supports hosting up to 50 Connected Products - Required for upgrading from version 3.x to current release of EBO
The Part Number: SWKSWASBUP4E5D is for ASB Upgrade Non-Secure Boot SpaceLogic Server - Standard - supports hosting up to 10 Connected Products - Required for upgrading from version 4.x to current release of EBO
The Part Number: SWKSWASBUP4EFU is for ASB Upgrade Non-Secure Boot SpaceLogic Server - Full - supports hosting up to 50 Connected Products - Required for upgrading from version 4.x to current release of EBO
The Part Number: SWKASBCON10001 is for AS-B Connector Kit including screw terminals for all AS-B models - Connectors must be ordered they are not included with controllers above!
The Part Number: SWKASBIN01001 is for AS-B Installer Kit including dummy unit with terminals to support easy wiring